

6132HD

IMPORTANT INFORMATION

When [NETWORK STANDBY] has been set for [STANDBY MODE] and the LAN has been in link-down condition for 3 minutes, [STANDBY MODE] will transit into [NORMAL] automatically for the purpose to save the consumption power.

- As the effect of [STANDBY MODE] transition to [NORMAL], the color of POWER indicator lit in orange will turn into red and some functions become ineffective.

- Effective connectors and functions in each standby mode are as follows:

NORMAL STANDBY

PC CONTROL connector, POWER buttons both on the cabinet and the remote control, VIRTUAL REMOTE TOOL with a serial connection, PC Control Utility Pro 4/5 with a serial connection.

NETWORK STANDBY

PC CONTROL connector, POWER buttons both on the cabinet and the remote control, MONITOR OUT connector, LAN functions, Virtual Remote Tool with a serial or LAN connection, PC Control Utility Pro 4/5 with a serial or LAN connection.

ERRATA for User's Manual

Page	Title	Original	Correct
49	CONTROL PANEL LOCK	Press and hold the EXIT button on the projector cabinet for about 10 seconds to turn off "CONTROL PANEL LOCK".	Press and hold the SOURCE button on the projector cabinet for about 10 seconds to turn off "CONTROL PANEL LOCK".
		Even when "NORMAL" mode is selected for "STANDBY MODE" and "ON" is selected for "CONTROL PANEL LOCK", the POWER button on the cabinet can be used to turn on the power.	When the CONTROL PANEL LOCK is ON, the POWER button on the cabinet can be used regardless of the setting for STANDBY MODE.