

Camera 446 Quick Start Guide




⚠ Important

Activate your warranty at www.dukaneav.com


Please visit the web site www.dukaneav.com for latest versions of the User manual, software guide and other details.

User Condition

* For the installation instruction, please refer to the [2. Installation & Connectoin](#) on the rear side.



1. Getting Started




- ① Place an object to be displayed under the camera.
- ② Turn the power on.
- ③ Adjust the gooseneck and lens to appropriate position.
- ④ Press the [AUTO TUNE] button to optimize the image. You are ready to teach / present.


* Each time the camera head is moved, press the [FOCUS] button to refocus the lens.

2. Installation & Connection

▼ Connect to a Projector or Monitor




▼ Connect to a Computer and Use Dukane Software




* Driver and software can be downloaded from Lumens website.

▼ Connect a Computer, Projector or Monitor simultaneously




* Press [SOURCE] button to switch the image source.

▼ Connect to an Interactive Whiteboard (IWB)



▼ Connect to an HDTV



▼ Connect to a Computer and FLASH Disk

